

Installation zur Änderung des Zeitstempels der CarCamOne

Installationsanweisung

1. Installieren Sie die Datei STKO2N 2.0. Zuvor Virusscanner deaktivieren! Zertifikatswarnungen von Microsoft ignorieren.
2. Computer neu starten
3. Kamera einschalten und "WC" im Auswahlnenue wählen.
4. Verbinden Sie die Kamera mit dem Computer
5. Starten Sie das Programm "RTCRW.exe"
6. Klicken Sie "SET HOST TIME INTO RTC".
7. Starten Sie die Kamera neu.
8. Drücken Sie die Menuetaste (obere) für 3 Sekunden und es erscheint "II": Zeitstempel aktiviert im Display.
Drücken Sie die Taste nochmals für 3 Sekunden erscheint "--": Zeitstempel deaktiviert.

ACHTUNG! Deinstallation durch erneutes "installieren" der Datei STKO2n 2.0.

Installation to synchronize the Timestamp

Installation

1. Install file STKO2N 2.0. Stp Virusscanners and ignore certification warnings from your Windows system.
2. Restart the PC
3. Switch on the cam, select "WC" in the menue.
4. Connect the cam to your PC.
5. Start the program "RTCRW.exe"
6. Click "SET HOST TIME INTO RTC".
7. Restart the Cam.
8. Press menue button for more then 3 Sec; Timstamp integrated indicated by "II", press once again, indecated by "--" the Timestamp is switched off.

Note! A second installation of STKO2N 2.0 will remove the tool from the computer!