

BSG II - GSM Kamera (Stand 21.5.2010)

ACHTUNG: Die PIN Abfrage der Mobilfunkkarte für die GSM Kamera muss abgeschaltet sein.

MMS Versand per „WAP“:

#145#Name#
#148#0#
#124#**MMSCenter#**
#125#**GatewayIP#GatewayPort#APN#APNUsername#APNpassword#**

Beispiel D2

Kamera für D2 konfigurieren, Versand erfolgt per „WAP“:

#145#vodafone# *(Eingabe ist nicht notwendig)*
#148#0#
#124#http://139.7.24.1/servlets/mms#
#125#139.007.029.017#9201#event.vodafone.de#

Beispiel EPlus

Kamera für EPlus konfigurieren, Versand erfolgt per „WAP“:

#145#eplus# *(Eingabe ist nicht notwendig)*
#148#0#
#124#http://mms/eplus.de#
#125#212.23.97.153#9201#mms.eplus.de#mms#eplus#

Beispiel O2

Kamera für O2 konfigurieren, Versand erfolgt per „WAP“:

#145#o2# *(Eingabe ist nicht notwendig)*
#148#0#
#124#http://10.81.0.7:8002#
#125#195.182.114.52#9201#wap.viaginterkom.de#

Wenn der Provider nur den Versand per „http“ unterstützt:

#148#1#
#149#0#**ISP#MMSC#**
#150#0#**GatewayIP#GatewayPort#APN#APNUsername#APNpassword#**

Beispiel D1

Kamera für T-D1 konfigurieren, Versand erfolgt per „http“:

#145#T-D1# *(Eingabe ist nicht notwendig)*
#148#1#
#149#0#0#http://mms.t-mobile.de/servlets/mms#
#150#0#172.028.023.131#8008#internet#iphone#password#

ISP = Name für den Service, kann mit „0“ (Null) angegeben werden

MMSC = MMSCcenter Adresse (für http)

Beispiel:

#148#1#
#149#0#eplus#<http://mms/eplus#>
#150#0#212.23.97.153#5080#mms.eplus.de#mms#eplus#

Category	Function	Command	User
Define the user	Add a master number to the device	(1) <u>#00#</u>	Master
	Change the master user's number	(2) <u>#14#NewMasterNumber#</u>	Master
	Change the password	(3) <u>#04#oldpassword#newpassword#</u>	Master
	Add a family number	(4) <u>#06#FamilyNumber#</u>	Master
	Add several family numbers	(5) <u>#06#FamilyNumber#...#FamilyNumber#</u>	Master
	Delete a family number	(6) <u>#113#FamilyNumber#</u>	Master
	Delete several family numbers simultaneously	(7) <u>#113#FamilyNumber#...#FamilyNumber#</u>	Master
	Delete all family numbers	(8) <u>#113#</u>	Master
	Add single emergency number on the device	(9) <u>#106#EmergencyNumber#</u>	Master
	Add several emergency numbers on the device	(10) <u>#106#EmergencyNumber#...#EmergencyNumber#</u>	Master
	Delete an emergency number	(11) <u>#107#EmergencyNumber#</u>	Master
	Delete several emergency numbers	(12) <u>#107#EmergencyNumber#...#EmergencyNumber#</u>	Master
	Delete all emergency numbers	(13) <u>#107#</u>	Master
Network parameter settings	Choose a network operator's MMS parameter from V900 device MMS list	(14) <u>#145#wap#name#</u>	Master
	Set sending MMS message via WAP	(15) <u>#148#0#</u>	Master
	Set MMS center for WAP	(16) <u>#124#MMScenter#</u>	Master
	Set APN parameters for WAP	(17) <u>#125#GatewayIP#GatewayPort#APN#APNusername#APNpassword#</u>	Master
	Sending MMS message via HTTP	(18) <u>#148#1#</u>	Master
	Add a network provider's ISP and MMSC onto the list	(19) <u>#149#0#ISP#MMSC#</u>	Master
	Add APN parameters onto the list	(20) <u>#150#0#GatewayIP#GatewayPort#APN#APNusername#APNpassword#</u>	Master
capture images	Capture one image and send to the user mobile	(21) <u>#03#</u>	Master Family
		(22) <u>#03#password#</u>	Guest
	Capture more than one image and send to the user mobile	(23) <u>#03#ImageQuantity#</u>	Master Family
		(24) <u>#03#Password#ImageQuantity#</u>	Guest
	Capture image(s) and send back to user's pre-set E-mail address	(25) <u>#03#ImageQuantity#1#</u>	Master Family
	Capture image(s) and send to appointed mobile or E-mail address	(26) <u>#30#NumberOrEmail#ImageQuantity#</u>	Master Family
		(27) <u>#30#Password#NumberOrEmail#ImageQuantity#</u>	Guest
E-mail settings	Add/modify an E-mail address	(28) <u>#108#EmailAddress#</u>	Master Family
	Delete all E-mail address	(29) <u>#109#</u>	Master

Category	Function	Command	User
Timed imaging	Enable timing sends MMS images	(30) #115#1#	Master
	Set time period to auto-send MMS image	(31)#116# <i>WorkDay#StartTime1#EndTime1#IntervalTime1#...#StartTime3#EndTime3#IntervalTime3#</i>	Master
	Disable timing send MMS image	(32) #115#0#	Master
Remote control	No SMS notification message upon arming or disarming V900 device via remote control	(33) #137#0#	Master Family
	Send SMS notification message upon arming or disarming V900 device via remote control	(34) #137#1#	Master Family
	Remove all remote controls from the device	(35) #111#	Master Family
Emergency alarm	Emergency Mode1(to dial)	(36) #39#0#	Master Family
	Emergency Mode2(to send SMS and MMS message)	(37) #39#1#	Master Family
infrared body detector	Activate infrared body detector (default)	(38) #118#1#	Master Family
	Deactivate infrared body detector	(39) #118#0#	Master Family
Motion detection	Deactivate motion detection	(40) #22#0#	Master Family
	Activate motion detection (default)	(41) #22#1#	Master Family
	Motion detection sensitivity	(42) #36# <i>grade#</i>	Master Family
	Condition of motion detection	(43) #141# <i>DetectedTimes# TimePeriod#</i>	Master Family
wireless sensor	Make V900 device enter loading mode and set corresponding alarm mode	(44) #05# <i>SensorDescription#</i>	Master Family
	Remove a wireless sensor	(45)#112# <i>SensorDescription#...#SensorDescription#</i>	Master Family
	Remove all wireless sensors	(46) #112#	Master Family
Arming or disarming V900 device	Arming V900 device manually	(47) #01#	Master Family
	Disarming V900 device manually	(48) #02#	Master Family
	Enable timing arms the device	(49) #128#1#	Master Family
	Set time period to arm the device	(50)#129# <i>WorkDay#ArmTime1#DisarmTime1#...#ArmTime3#DisarmTime3#</i>	Master Family
	Disable timing arm the device	(51) #128#0#	Master Family
	Activate auto-disarming the device	(52) #138#1#	Master Family
	Set the value of alarm times when V900 device is auto-disarming	(53) #139# <i>times#</i>	Master Family
	Disable the function of auto-	(54) #138#0#	Master

Category	Function	Command	User
	disarming the device		Family
language setting	The user's first language (or Spanish) version	(55) <u>#127#0#</u>	Master
	English version	(56) <u>#127#1#</u>	Master
Check status	Check the present settings and work status of the device	(57) <u>#07#</u>	Master Family
		(58) <u>#07#password#</u>	Guest
Getting help	Getting normal command list via SMS	(59) <u>#09#</u>	Master Family
		(60) <u>#09#password#</u>	Guest
	Getting detailed instruction via MMS	(61) <u>#09#1#</u>	Master Family
		(62) <u>#09#password#1#</u>	Guest
Reset	Reset the device	(63) <u>#08#password#</u>	Master
Image settings	Image size	(64) <u>#32#value#</u>	Master Family
	Image quantity	(65) <u>#33#quantity#</u>	Master Family
	Image brightness	(66) <u>#34#value#</u>	Master Family
	Image direction	(67) <u>#35#value#</u>	Master Family
	Image contrast	(68) <u>#38#value#</u>	Master Family
	Image compressibility	(69) <u>#119#value#</u>	Master Family
	Image Interval	(70) <u>#103#time#</u>	Master Family
Automatic alarm settings	Warning tone upon alarm triggering	(71) <u>#130#1#</u>	Master Family
	No warning tone upon alarm (Default)	(72) <u>#130#0#</u>	Master Family
	No SMS notification upon alarm	(73) <u>#11#0#</u>	Master Family
	SMS notification upon alarm (Default)	(74) <u>#11#1#</u>	Master Family
	No MMS notification upon alarm	(75) <u>#12#0#</u>	Master Family
	MMS notification upon alarm (Default)	(76) <u>#12#1#</u>	Master Family
	No call notification upon alarm (Default)	(77) <u>#13#0#</u>	Master Family
	Call notification upon alarm	(78) <u>#13#1#</u>	Master Family
	No MMS notification to pre-set E-mail address (Default)	(79) <u>#110#0#</u>	Master Family
	MMS notification to pre-set E-mail address	(80) <u>#110#1#</u>	Master Family
Lights	Turn off indicator	(81) <u>#143#0#</u>	Master Family
	Turn on indicator	(82) <u>#143#1#</u>	Master Family
	Turn off infrared lights during arming the device	(83) <u>#31#0#</u>	Master Family
	Turn on infrared lights during arming the device	(84) <u>#31#1#</u>	Master Family

Category	Function	Command	User
SMS notification and reply	SMS notification upon the power supply changing (Default)	(85) <u>#144#1#</u>	Master Family
	No SMS notification upon the power supply changing	(86) <u>#144#0#</u>	Master Family
Temperature sensor	Get temperature and humidity from sensor	<u>#159#</u> V900 device will reply the environment temperature and humidity value via SMS to the user. If V900 device did not receive any data from the sensor before, then it will reply 0,0.	Master Family
	Set temperature range to arm the temperature sensor	<u>#163#Data1#Data2#</u> Data1: the temperature low limit. It can not be under -40°C. Data2: the temperature upper limit. It can not be higher than 70°C. If the environment temperature is lower than data1 or higher than data2, V900 device will send the temperature value via SMS to the Master user and disarm the temperature sensor. It needs to arm the temperature sensor again.	Master Family